

ADDICTIVE DESERT DESIGNS

2015 – Current F150 Straight or Radius Cab Mount Installation Instructions

PREPARATION

1. Disconnect the negative terminal on the battery. Park the vehicle on level ground and set the emergency brake.
2. We recommend reading through the installation instructions in whole before performing the work.
3. Estimated Installation Time: **1 Hour**
4. You will need the following tools:
 - a. Drill
 - b. 1/4" Drill Bit
 - c. Tape Measure
 - d. Rivet Gun

Note: this installation requires 2 people for best results

5. Included in Kit:
 - 1 – Left Mount
 - 1 – Right Mount
 - 6 – Rivets – 1/4"

INSTALLATION

1. Mount light bar into both Roof Mounts to create an assembly. (Fig A)



Fig A

2. Measure mount locations by measuring 23 3/8" from the lower pillar (where it meets the fender) to the bottom edge of the Cab Mount. Do this for both sides of the truck. (Fig B)




Fig B

3. With the bracket in place, mark and drill the three holes with a 1/4" Drill Bit. Install the rivets and bracket according to the rivet tool manufacturer's instructions. Repeat this step on the other side.
4. To wire your light, follow the light manufacturer's installation instructions.
5. Stand back and enjoy your new ADD Cab Mounts.



**For Additional Support or Technical Questions,
Please Call 480.671.0820 or
Email info@addictivedesertdesigns.com**