

ADDICTIVE DESERT DESIGNS

2015 – Current Chevy Colorado Cab Mount Installation Instructions

PREPARATION

1. Disconnect the negative terminal on the battery. Park the vehicle on level ground and set the emergency brake.
2. We recommend reading through the installation instructions in whole before performing the work.
3. You will need the following tools:
 - a. Rivet Gun
 - b. 1/4" Drill Bit
 - c. Drill
 - d. Tape Measure

Note: this installation requires 2 people for best results

4. Included in Kit:
 - 2 – Cab Mount Pieces (Right and Left)
 - 6 – Rivets – 1/4"

INSTALLATION

1. Mount light bar into both Cab Mount Pieces to create an assembly. (Fig A)



Fig A

2. Carefully measure mount locations by measuring 16 3/4" from where the lower pillar meets the fender to the bottom of the mount. Do this for both sides of the truck. (Fig B)



Fig B

3. With the bracket in position, mark and drill the three holes with a 1/4" drill bit and install the rivets and bracket according to the rivet tool manufacturer's instructions. Repeat for the other side of the vehicle.
(Fig C)



4. Wire the light according to the light manufacturer's instructions.
5. Stand back and enjoy your new ADD Light Mount.
6. Check and re-tighten if needed, all mounting bolts after 100 miles and periodically thereafter.



**For Additional Support or Technical Questions,
Please Call 480.671.0820 or
Email info@addictivedesertdesigns.com**