

ADDICTIVE DESERT DESIGNS

2005 - 2014 Toyota Tacoma Straight & Radius Cab Mounts Installation Instructions

PREPARATION

1. Disconnect the negative terminal on the battery. Park the vehicle on level ground and set the emergency brake.
 2. We recommend reading through the installation instructions in whole before performing the work.
 3. Estimated Installation Time: **1 Hour**
 4. You will need the following tools:
 - a. Drill
 - b. 1/4" Drill Bit
 - c. Tape Measure
 - d. Rivet Gun
- Note: this installation requires 2 people for best results*
5. Included in Kit:
 - 1 – Left Mount
 - 1 – Right Mount
 - 6 – Rivets – 1/4"

INSTALLATION

1. Mount light bar into both Roof Mounts to create an assembly. (Fig A)



Fig A

2. Measure the mount locations by measuring 16 1/4" from the lower pillar (where it meets the fender) to the bottom of the cab mount. Do this for both sides of the truck. (Fig B)



Fig B

3. With the bracket in position, mark and drill the three holes with a 1/4" Drill Bit. Install the rivets and bracket according to the rivet tool manufacturer's instructions. Repeat this step on the other side.
4. To wire your light, follow the light manufacturer's installation instructions.
5. Stand back and enjoy your new ADD Cab Mounts.



**For Additional Support or Technical Questions,
Please Call 480.671.0820 or
Email info@addictivedesertdesigns.com**