

ADDICTIVE DESERT DESIGNS

2007.5 – 2013 Chevy/GMC 1500 & 2500 Cab Mount Installation Instructions

PREPARATION

1. Disconnect the negative terminal on the battery. Park the vehicle on level ground and set the emergency brake.
 2. We recommend reading through the installation instructions in whole before performing the work.
 3. Estimated Installation Time: **1 Hour**
 4. You will need the following tools:
 - a. Drill
 - b. 1/4" Drill Bit
 - c. Tape Measure
 - d. Rivet Gun
- Note: this installation requires 2 people for best results*
5. Included in Kit:
 - 1 – Left Mount
 - 1 – Right Mount
 - 6 – Rivets – 1/4"

INSTALLATION

1. Mount light bar into both Roof Mounts to create an assembly. (Fig A)



Fig A

2. Carefully line up the front side of the base of the mount with the corner of the cab before it meets the windshield. (Fig B)



3. With the bracket in position, mark and drill the three holes with a 1/4" Drill Bit. Install the rivets and bracket according to the rivet tool manufacturer's instructions. Repeat this step on the other side.
4. To wire your light, follow the light manufacturer's installation instructions.
5. Stand back and enjoy your new ADD Cab Mounts.



**For Additional Support or Technical Questions,
Please Call 480.671.0820 or
Email info@addictivedesertdesigns.com**