



INSTALLATION GUIDE

2025-UP/RAM RHO

PHANTOM FRONT BUMPER

F630263200103



TOOLS REQUIRED

(Torx) T40

(Allen) 3/16, 5/32, 7/32, 5/16

(Wrench) 8mm, 10mm, 13mm, 16mm, 18mm, 21mm, 1/32, 9/16, 3/4

(Socket) 8mm, 10mm, 13mm, 16mm, 18mm, 21mm, 1/32, 9/16, 3/4

Ratchet

Flat Head/Fastener Remover



TIME REQUIRED

- 3 hours for OEM Removal/Bumper Install

-1 Additional Hour to Wire Lights

****Labor Rates are based on a vehicle with no pre-existing damage. Wiring labor is based on a standard wiring procedure with light switches installed in an easily accessible location. Custom light triggering or switch mounting location will result in a greater labor charge.****



SKILL LEVEL



Easy

****This installation requires 2 people for best results****



WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION



-BEFORE YOU INSTALL THIS KIT-

Read and understand all instructions, warnings, cautions, & notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.

Customer Service (480) 671-0820

Addictive desert designs is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components.

We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these

components and the safety of the vehicle.

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information:

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

***ALWAYS WEAR EYE PROTECTION
WHEN OPERATING POWER TOOLS***



INSTALLATION GUIDE

HARDWARE

A.



#8-32 X 3/4" BUTTON HEAD BOLT

QTY: 4

A1.



#8-32 NYLON LOCK NUT

QTY: 4

A2.



#8 FLAT WASHER

QTY: 4

B.



1/4-20 X 3/4" BUTTON HEAD BOLT

QTY: 16

B1.



1/4" FLAT WASHER

QTY: 16

B2.



1/4-20" NYLON LOCK NUT

QTY: 16

C.



3/8-16 X 3/4" BUTTON HEAD BOLT

QTY: 6

C1.



3/8-16 X 1" BUTTON HEAD BOLT

QTY: 2

C2.



3/8 FLAT WASHER

QTY: 8

C3.



3/8-16" NYLON JAM NUT

QTY: 8

D.



1/2-13 X 1 1/2" BUTTON HEAD BOLT

QTY: 4


D1.



1/2" FLAT WASHER

QTY: 8

D2.



1/2-13" NYLON LOCK NUT

QTY: 4

E.



MOPAR CLIP ON SENSOR BEZEL

QTY: 4

E1.



MOPAR CLIP ON SENSOR BACKER


QTY: 4



INSTALLATION GUIDE

PARTS

F.



SPH0227

QTY: 2

G.



SPH0006, SPH0006-M

QTY: 1


H.



SPH0007, SPH0007-M

QTY: 1

I.



SPH0239, SPH0239-M

QTY: 1

J.



SPH0225, SPH0225-M

QTY: 6




INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 1

Using a (16mm Socket), remove the skid plate mounting bolts (x6). ****Keep Hardware**** Then, remove the skid plate from the vehicle. From underneath the vehicle, unplug the main bumper harness connector located on the driver side and passenger side of the vehicle along the frame rail.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 2

Using a (Fastener Removal Tool) remove all 12x push pins holding the top shroud located underneath the hood. ****Keep hardware****






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 3

Using a (8mm socket) remove the 8x bolts highlighted below. ****Keep hardware****






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 4

Using a (8mm socket) remove the bolts located in the wheel well for the fender flair. ****Keep hardware****





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 5

Pop the fender flair off by pulling outwards.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 6

Using a (10mm socket) remove the 2x bolts located above the headlight. ****Keep hardware****






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 7

Remove the plastic cover as shown below to expose the blind spot sensor. Next unplug the sensors and set plastic aside.



UNPLUG


PHANTOM FRONT BUMPER

2025-UP/RAM RHO

REMOVAL

□ STEP 8

Using an (8mm Socket), remove the two bolts (per side) along the front portion of each front wheel well. Then using a (13mm Socket), remove the three bolts (per side) that hold the oil cooler to the vehicle for easy access to the mount bolts.






PHANTOM FRONT BUMPER

2025-UP/RAM RHO

REMOVAL

□ STEP 9

Using an (18mm Socket), remove the three mounting nuts (per side) that hold the bumper to the vehicle. Then, remove the bumper from the vehicle. Then use an (18mm socket) and (21mm Socket) to remove the two tow hook.





INSTALLATION GUIDE


PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 10

This step is optional and is done for aesthetics. Use a cutoff wheel to trim the inner fender mounting bracket as shown bellow. Make sure to paint over any bare metal.

Before



After






PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 11

Use an (8mm Socket) to remove the three mounting bolts (per side) that hold the inner liner to the bumper. Remove the fog lights from the OEM bumper. To do this, remove the two vertical facing bolts (T40 Torx Socket) along the top side of the fog light. Then, remove the (10mm bolt) and nut along the bottom side of the fog light piece. Unplug the fog light and remove.





PHANTOM FRONT BUMPER 2025-UP/RAM RHO

REMOVAL

□ STEP 12

Use an (8mm Socket) to remove the mounting nuts that hold the fog light trim piece and the sensor bezels. Then use a (10mm Socket) to remove the four bolts that hold the plastic trim piece to the edge of the OEM bumper. Then, remove that piece and use a Phillip's Head Screwdriver to remove the two marker light mounting screws. Remove the marker lights from the bumper.




PHANTOM FRONT BUMPER 2025-UP/RAM RHO


REMOVAL

□ STEP 13

Remove the four parking sensors from their mounting rings. To do this, spread the tabs on the back side of the rings and push the sensors out the back side. Then remove the bezels. Make sure to keep track of the position/orientation they come off your OEM bumper so you can reinstall them in the same position/orientation on your new bumper. ****Only remove the 2 inner sensor bezels NOT the outer bezels****



Spread these two tabs to release the parking sensor from its mounting ring



Squeeze these two tabs to release the mounting rings from the bumper


PHANTOM FRONT BUMPER

2025-UP/RAM RHO

REMOVAL

□ STEP 14

Remove the ACC module from the bumper and follow the ACC relocation bracket install guide located on our website and come back to finish the install.





INSTALLATION GUIDE



PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 15

Now would be a good time to install the lights.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 16

Install the **(G, H)** light mount brackets with the provided **(B, B1, B2)** 1/4" hardware using (5/32 allen) and a (7/16 wrench). (Repeat on other side)

OUTSIDE

INSIDE

SHORT

LONG






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 17

Install the OEM marker lights with the provided (A, A1, A2) #8 Bolts using a (3/16 allen) and a (1/32 wrench). **Do not over tighten bolts due to breakage**





PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 18

Install the (J) outer parking sensor mounts with the provided (B, B1, B2) 1/4" hardware using a (5/32 allen) and (7/16 wrench). (Repeat on other side)





INSTALLATION GUIDE




PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 19

Install the **(I)** parking sensor mounts on the inner and mid section located above the top mounting hole with the provided **(B, B1, B2)** 1/4" hardware using a (5/32 allen) and (7/16 wrench). (Repeat on other side)





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL





PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 20

On the two outer sensor locations install the sensors in the provided **(E, E1)** bezels with the skinny side facing up. You will notice that one side will be oriented the same as factory and the driver side will be 180 degrees opposite. ****Also note that the sensor plug needs to be 90 degrees to the ground**** If your sensor bezel is loose in the bumper and can easily be rotated we recommend applying a small dab of silicone or epoxy to the back side to prevent them from rotating. This step will apply to all aftermarket sensor bezels throughout the install.

****Do not install the middle sensors and bezels. That is for later on in the install****



**E.
E1.**



INSTALLATION GUIDE


PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 21

Install the inner two parking sensor bezels in the same orientation as OEM.







INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 22

Install the skid plate to your bumper with the provided (**C**, **C1**, **C2**, **C3**) 3/8" hardware using a (7/32 allen) and a (9/16 wrench).





INSTALLATION GUIDE



PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 23

Install the bottom mounting bracket to the skid plate with the provided **(C, C2, C3)** 3/8" hardware using a (7/32 allen) and a (9/16 wrench).






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 24

With a helping hand, install the bumper with the provided (D, D1, D2) 1/2" hardware using a (5/16 allen) and a (3/4 wrench).





INSTALLATION GUIDE



PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 25

Next, install the provided **(D, D1, D2)** 1/2" hardware into the top mounting holes using a (5/16 allen) and a (3/4 wrench).

Tech Tip: Leave the sensor and bezel removed on the highlighted areas below for tool access. Then finish installing the sensor and bezel after you have the desired fitment.






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 26

Using the provided (F) shim plates, install on either driver, passenger or both to ensure you have an even gap reveal between the bumper and the grill as shown below.







INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL





INSTALLATION GUIDE

PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 27

Install the skid plate using a (16mm socket) with the OEM hardware removed from **step 1**.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 28

Ensure to have the ACC plugged in before moving on with the install. Then re-install the plastic removed from **step 7**, ensure to plug in the blind spot sensors before installing.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER

2025-UP/RAM RHO

INSTALL

□ STEP 29

Using a (10mm socket) install the 2x bolts located above the headlight.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 30

Re-install the fender flair.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 31

Using a (8mm socket) install the bolts located in the wheel well for the fender flair.






INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

□ STEP 32

Using a (8mm socket) install the 8x bolts highlighted below.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

INSTALL

☐ STEP 33

Install all 12x push pins holding the top shroud located underneath the hood.





INSTALLATION GUIDE

PHANTOM FRONT BUMPER 2025-UP/RAM RHO

FINAL

□ STEP 34

Stand back and enjoy your new ADD Phantom Front Bumper.

Check and re-tighten all mounting bolts after 100 miles and periodically thereafter.



THIS PRODUCT IS PROTECTED BY ONE OR MORE U.S. PATENTS
WWW.ADDICTIVEDESERTDESIGNS.COM/PATENTS

FOR ADDITIONAL SUPPORT OR TECHNICAL QUESTIONS,
PLEASE CALL 480-671-0820 OR
EMAIL INFO@ADDICTIVEDESERTDESIGNS.COM