

ADDICTIVE DESERT DESIGNS

2007 - Current Toyota Tundra Straight Bar Roof Mount Installation Instructions

PREPARATION

1. Disconnect the negative terminal on the battery. Park the vehicle on level ground and set the emergency brake.
 2. We recommend reading through the installation instructions in whole before performing the work.
 3. Estimated Installation Time: **1 Hour**
 4. You will need the following tools:
 - a. Drill
 - b. 1/4" Drill Bit
 - c. Tape Measure
 - d. Rivet Gun
- Note: this installation requires 2 people for best results*
5. Included in Kit:
 - 1 – Left Mount
 - 1 – Right Mount
 - 6 – Rivets – 1/4"

INSTALLATION

1. Mount your light bar into both Roof Mounts to create an assembly. (Fig A)



Fig A

2. Carefully measure mount locations by measuring 18 1/2" from the lower pillar at the fender to the bottom most point of the roof mount. Do this for both sides of the truck. (Fig B)



Fig B

3. With the bracket in position, mark and drill the three holes with the 1/4" Drill Bit and install the supplied 1/4" Rivets (according to the rivet tool manufacturer's instructions) and bracket. Repeat this step on the other side. (Fig C)



Fig C

4. Wire your light according to the light manufacturer's installation instructions.
5. Stand back and enjoy your new ADD Roof Mount.





For Additional Support or Technical Questions,
Please Call 480.671.0820 or
Email info@addictivedesertdesigns.com